








Electrical preheater





Installation instruction





Rev. 1.1

Dantherm[®]
CONTROL YOUR CLIMATE



	1	
<p>Tools  TX 20</p>	2	
	3	




	7	
<p>Tools  TX 20</p>	8	
	9	

	10	
<p>Tools  TX 20</p>	11	
	12	


13








14






15



	16	
<p>Tools  TX 20</p>	17	
	18	

	19	
<p>Tools</p>  <p>TX 20</p>	20	
	21	

	22	 <p>On = ON Off = OFF</p>
<p>Tools  TX 20</p>	23	



081 502

Dantherm Air Handling A/S

Marienlystvej 65
7800 Skive
Danmark
www.dantherm.com
service@dantherm.com

Dantherm®
CONTROL YOUR CLIMATE